



电流/电压显示

8.8.8.8

功率调节

POWER ADJ

CURRENT/VOLTAGE DISPLAY

电源开关

POWER SWITCH

开 ON

关 OFF

电源 工作 过流 超温  
POWER WORK OC OT

MIN 小

大 MAX

电流

CURRENT

电压

VOLTAGE


显示转换  
DISPLAY DIVERSION

FULL SOLIDITY SERIES INDUCTION HEATING POWER SUPPLY

1 2 3 4 5 6 7 8







Quick Coil change



Regular Coil, for brazing router bits, shaper cutters



Foot Pedal : Included

